


Installation recommendations



- To install '**Loader for METRIX Oscilloscopes**' software requires a minimum of 100 Mb disk space.
The installation is carried out by default, in directory '**C:\LoaderScope**'.
- It is strongly recommended not to use the PC during this operation.
- Update duration: It takes 20 to 30 minutes by the serial link, from 8 to 10 minutes via USB.
- Power up: If you use a laptop, connect it to mains power to prevent battery failure.
For SCOPIX oscilloscopes, the update must be performed with the charger connected between the mains and the device.
- USB Driver to be installed: oscilloscopes MTX 3354 and MTX 3x52 V3.x use the USB port. The drivers are available in directory '**C:\LoaderScope\DriverUSB**'.

If, despite these recommendations, you cannot update, contact technical support : support@chauvin-arnoux.fr

Observe the following steps

Steps	Actions
1.	Download ' Loader for METRIX Oscilloscopes '. Install it on the PC.
2.	Start ' Loader for METRIX Oscilloscopes '. Select the oscilloscope model and, if necessary, its type of LCD screen (monochrome or colour). <div data-bbox="582 1131 1444 1966" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> </div>
3.	Click on the  button and follow instructions on screen.



Consejos de instalación



- Para instalar el software '**Loader for METRIX Oscilloscopes**' se requiere como mínimo 100 Mo de espacio en el disco.
Por defecto, al instalación se hace en el repertorio '**C:\LoaderScope**'.
- Se aconseja insistentemente no trabajar en el PC durante esta operación.
- Duración de la actualización: toma de 20 a 30 minutos por el enlace serie, de 8 a 10 minutos por USB.
- Muestra bajo tensión: si utiliza un ordenador portátil, conéctelo a la red eléctrica para evitar una descarga de la batería.
Para los osciloscopios SCOPIX, hacerlo obligatoriamente con el cargador conectado entre la red eléctrica y el aparato.
- Driver USB a instalar: los osciloscopios MTX 3354 y MTX 3x52 v3.x utilizan el puerto USB. Los drivers están disponibles en el repertorio '**C:\LoaderScope\DriverUSB**'.

Si, a pesar de estos consejos, no puede efectuar la actualización, contacte con el soporte técnico support@chauvin-arnoux.fr

Respete las etapas siguientes

Etapas	Acciones
1.	Telecargue ' Loader for METRIX Oscilloscopes '. Instálelo en el PC.
2.	<p>Lance 'Loader for METRIX Oscilloscopes'. Seleccione el modelo de osciloscopio y, si procede, son tipo de pantalla LCD (monocroma o a color).</p> 
3.	Haga clic en el botón  y siga las instrucciones en la pantalla.