



Install instructions



- To install '**Loader for METRIX Oscilloscopes**' software requires a minimum of 200 Mb disk space.
The installation is carried out by default, in directory '**C:\LoaderScope**'.
- It is strongly recommended not to use the PC during this operation.
- Update duration: It takes 20 to 30 minutes by the serial link, from 8 to 10 minutes via USB.
- Power up: If you use a laptop, connect it to mains power to prevent battery failure.
For SCOPIX and HANDSCOPE oscilloscopes, the update must be performed with the charger connected between the mains and the device.
- USB Driver to be installed: MTX 3354, MTX 3x52 V3.x and HANDSCOPE oscilloscopes use the USB port. The drivers are available in directory '**C:\LoaderScope\DriverUSB**'.

Observe the following steps

Steps	Actions
1.	Download ' Loader for METRIX Oscilloscopes '. Install it on the PC.
2.	<p>Start 'Loader for METRIX Oscilloscopes'.</p> <p>Select the oscilloscope model and, if necessary, its type of LCD screen (monochrome or colour).</p> 
3.	Click on the  button and follow instructions on screen.