



Phase & Motor Rotation Meter Model 6609

Cat. #2121.11

Operating voltages: Leads Connected 40 to 600V_{AC} Between Phases, Unconnected 120 to 400V_{AC} Between Phases, Frequency range 15 to 400HZ

Verify proper phase wiring, detect open or de-energized phases and determine correct wiring for proper rotation on motors, pumps, etc.

Cat.#2121.11

Phase Rotation Connection Method	Direct Connection with Color-coded Leads
Rotating Field Connection Method	Non-Contact Static Induction
Operating Voltages	Leads Connected: 40 to 600V _{AC} Between Phases; Unconnected: 120 to 400V _{AC} Between Phases
Frequency Range	15 to 400Hz
Phase Rotation Indicator	LEDs for Left or Right Rotation
Power Supply	One 9V Alkaline Battery (Included)
Dimensions	5.1 x 2.7 x 1.3" (130 x 69 x 32mm)
Weight	6 oz (170g)
Operating Temperature	32° to 104°F (0° to 40°C)
Storage Temperature	-4° to 122°F (-20° to 50°C)
Relative Humidity	<80%
Safety Compliance	IEC 61010-1; 600V CAT III
Ingress Protection	IP 40

For more details, download the datasheet or user manual at www.aemc.com

15 Faraday Drive • Dover, NH 03820 USA • (800) 343-1391 • (603) 749-6434 • www.aemc.com

customerservice@aemc.com • techsupport@aemc.com

CE Approved

Yes

For more details, download the datasheet or user manual at www.aemc.com

15 Faraday Drive • Dover, NH 03820 USA • (800) 343-1391 • (603) 749-6434 • www.aemc.com
customerservice@aemc.com • techsupport@aemc.com

