GROUND RESISTANCE TESTERS

MULTI-FUNCTION

GROUNDFLEX® FIELD KIT

Test active tower grounds safely without de-energizing or disconnecting any cables

Unique in the industry!

SPECIFICATIONS





| MODELS | 6472 & 6474 | | | | | | | | |
|--|--|------------------------|--|----------------------------|------------------------------------|---|---------------------------------------|--|--|
| ELECTRICAL | 3-POINT & SELECTIVE METHODS | | GROUND MEASUREMENT WITH 2 CLAMPS | SOIL RESISTIVITY | GROUND POTENTIAL MEASUREMENT | DC RESISTANCE MEASUREMENT | MEASUREMENTS WITH 6474 | | |
| Range (Auto-Ranging) | 0.09 Ω to 99.9 kΩ | 0.011 Ω to 99.99 kΩ | (0.1 to 500) Ω | 0.01 Ω to 99.9 kΩ | 0.01 mV to 65.00 V | 0.02 Ω to 99.99 kΩ | 0.067 Ω to 99.99 kΩ | | |
| Resolution | (0.01 to 100) Ω | (0.001 to 10) Ω | (0.01 to 1) Ω | (0.01 to 100) Ω | (0.01 to 10) mV | 2 wires: $(0.01 \text{ to } 100) \Omega$ 4 wires: $(0.001 \text{ to } 10) \Omega$ | (0.001 to 10) Ω | | |
| Accuracy | ± (2 % + | - 1 count) | ± (10 % + 1 count) | ± (2 % + 1 count) | ± (5 % + 1 count) | ± (2 % + 2 counts) | ± (5 % + 1 count) | | |
| No-Load Voltage | (| (10, 16, 32 or 60) | Vrms (Not applicable | w/2-clamp metho | ± 16 VDC | (10, 16, 32 or 60) Vrms | | | |
| Measurement Frequency | (41 to 5078) Hz | | Auto: 1611 Hz Manual: (128, 1367, 1611, or 1758) Hz | (41 to 128) Hz | (41 to 128) Hz (41 to 5078) Hz | | (41 to 5078) Hz | | |
| Coupling Measure- ment | Yes | | , | | _ | | | | |
| Auxiliary Rod Resistance Measurement | 0.14 Ω to | o 99,9 kΩ | | - | | | | | |
| Voltage Interference | | | | Maximum 60 V p | eak | | | | |
| Soil Resistivity | | _ | | Wenner and Schlumberger | | _ | _ | | |
| Type of Measurement | 3 wires | 4 wires | 2 clamps | 4 wires | 3 wires | 2 or 4 wires | GroundFlex® | | |
| Measurement Current | > 200 mAac | | < 26 Arms (w/SR182) < 5 Arms (w/MN82) | > 200 mAac | | > 200 mAdc | > 200 mAac | | |
| MECHANICAL | | | , | | | | | | |
| Memory/ Communication | 512-record memory / Optically isolated USB | | | | | | | | |
| Dimensions/Weight | (10.7 x 9.84 x 5.04) in (272 x 250 x 128) mm / Model 6472: 7.05 lb (3.2 kg) / Model 6474: 5.07 lb (2.3 kg) | | | | | | | | |
| Safety | , | , i | , | | | | · · · · · · · · · · · · · · · · · · · | | |
| Safety Rating | | 50 | V CAT IV, complies v | vith IEC 61326-1 / I | EC 61010 / IEC 61 | 557-1-4-5 | | | |

Consult factory for NIST Calibration prices

GROUND TESTER 6472 KIT-500 FT

Includes meter, rechargeable NiMH batteries, optical USB cable, power adapter (110/240) V with power cord 115 V US, (2) 500 ft color-coded leads on spools (red/blue), (2) 100 ft color-coded leads (hand-tied, green/black), (1) 30 ft lead (green), (4) T-shaped auxiliary ground electrodes, (1) 100 ft AEMC® tape measure, DataView® software, ground tester workbook, user manual on USB drive, (1) carrying bag for meter and (1) carrying bag for kit.

GROUNDFLEX® FIELD KIT 6474

Catalog #2136.03 (Includes Ground Tester 6472 KIT-500 FT)

Includes GroundFlex® Adapter Model 6474, Ground Tester Model 6472, (4) GroundFlex® sensors (16 ft/5 m) with (12) color-coded rings, connection lead, (2) extension leads on H reel (black/green) with color-coded alligator clips, (1) extra black and green alligator clip, (6) BNC extension leads, (1) calibration loop, (3) C-clamps, a carrying case with wheels and handle for meters, carrying bag for meter and kit, (1) inverter 12 Vpc to 120 Vac 200 watt (vehicle use) and user manual.





GROUND RESISTANCE TESTERS

GROUNDFLEX® FIELD KIT


FEATURES

- Ground Integrity Measurement
- 3- and 4-Point Fall-of-Potential measurement with manual or automatic frequency selection
- 4-Point soil resistivity measurement with automatic calculation of Rho (p) and user selection of the Wenner or Schlumberger test method
- 2- and 4-Wire DC resistance measurement (Bond testing) with automatic polarity reversal
- 3-Point Earth coupling measurement
- Automatic frequency scan from (41 to 5078) Hz for optimum test accuracy in electrically noisy environments
- Selectable test voltage limit of (10,16, 32, or 60) V with up to 250 mA of test current
- · Automatic recognition of all electrode connections and measurement of their resistance value
- Determines bonding condition of overhead ground conductors
- Auto Power OFF management
- · Optically isolated USB communication
- · Remote set up and operation of all measurements using DataView® software supplied
- Rechargeable NiMH batteries from wall charger or vehicle power (Cat. #2135.43 needed for vehicle
- · Rugged dustproof and water-resistant field case (IP53 rated in closed position)
- Includes DataView® software for data retrieval, real-time display, analysis, automatic report generation and system configuration

AUTOMATIC RECOGNITION AND DISPLAY OF INPUT CONNECTIONS TO MATCH TEST

The connections are displayed and flash if incorrect or absent for the test selected.





GROUND MEASUREMENT ON TOWERS WITH GROUND CABLE

High-voltage lines are usually equipped with a ground cable to allow lightning to discharge to ground via the tower. As all the towers are connected to this conductor, all the tower's resistances are in parallel. This means it is impossible to measure tower resistance using traditional 3-Point methods unless the ground cable is disconnected, which is a dangerous and time-consuming operation.

ACCESSORIES

CAT #2135.87

GroundFlex® Sensor 32 ft (10 m) (Model 6474 only)

CAT #2135.72

Model SR182 **AC Current Probe** (Models 6471 & 6472)

CAT #2135.86

Lead - BNC 150 ft (46 m) M/F Extension Lead (Model 6474 only)







CATALOG NO.

DESCRIPTION

GroundFlex® Field Kit Model 6474 (Tower Tester)



GROUND RESISTANCE TESTERS SELECTION CHART

| AEMC Model Number | AEMC CATALOG NUMBER | RESISTANCE Range | POWER Source | 2 Point Test | 3 POINT TEST | 4 Point/ Selective | SOIL RESISTIVITY TEST | EARTH COUPLING | 2 CLAMP | DISPLAY | ADJUSTABLE Frequency | SWEEP FREQUENCY |
|--|---------------------------|--------------------------------------|-------------------------|--------------------|--------------------|--------------------------|-----------------------------|-------------------|--------------|---------|-------------------------|--------------------|
| 6422 | 2135.55 | 0.05 Ω to 2 kΩ | Battery | ✓ | , | -/- | | _ | | Digital | Auto (128 or 256) Hz | - |
| 6422 Kit 150 FT | 2135.56 | 0.05 Ω to 2 $k\Omega$ | Battery | ✓ | , | -/- | | - | | Digital | Auto (128 or 256) Hz | - |
| 6424 | 2135.57 | 0.05 Ω to 50 k Ω | Rechargeable Battery | ✓ | • | -/- | | - | | Digital | Auto (128 or 256) Hz | - |
| 6424 Kit 150 FT | 2135.58 | $0.05~\Omega$ to $50~\text{k}\Omega$ | Rechargeable Battery | ✓ | | -/- | | _ | | Digital | Auto (128 or 256) Hz | _ |
| 6424 Kit 300 FT | 2135.59 | 0.05 Ω to 50 kΩ | Rechargeable Battery | ✓ | | -/- | | _ | | Digital | Auto (128 or 256) Hz | _ |
| GroundFlex® Field Kit Model 6474 | 2136.03 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | - | ✓ | √/- | ✓ | , | - | Digital | Auto (41 to 5078) Hz | ✓ |
| 6471 (SR182 probes not included) | 2135.48 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | ✓ | • | √/√ | ~ | , | √ *** | Digital | Auto (41 to 513) Hz | ✓ |
| 6471 | 2135.49 | 0.001 Ω to 99.99 k Ω | Rechargeable Battery | ✓ | • | √/√ | | \checkmark | | Digital | _ | ✓ |
| 6471 Kit 300 FT (with probes) | 2135.50 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | √ | , | √/√ | | √ | | Digital | _ | ✓ |
| 6471 Kit 300 FT (no probes) | 2135.60 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | ✓ | • | √/√ | | ✓ | | Digital | Auto (41 to 513) Hz | ✓ |
| 6471 Kit 500 FT (no probes) | 2135.61 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | ✓ | , | √/√ | | ✓ | | Digital | Auto (41 to 513) Hz | ✓ |
| 6472 | 2135.51 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | ✓ | | √/√ | ✓ | , | √ *** | Digital | Auto (41 to 5078) Hz | ✓ |
| 6472 Kit 300 FT | 2135.53 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | ✓ | | √/√ | ✓ | • | √*** | Digital | Auto (41 to 5078) Hz | ✓ |
| 6472 Kit 500 FT | 2135.54 | 0.001 Ω to 99.99 kΩ | Rechargeable Battery | ✓ | • | √/√ | ✓ | • | √ *** | Digital | Auto (41 to 5078) Hz | ✓ |
| 4620 | 2130.43 | (0.0 to 1999) Ω | Battery | ✓ | • | √/- | ✓ | _ | | Digital | _ | |
| 4620 Kit 150 FT | 2135.19 | (0.0 to 1999) Ω | Battery | ✓ | , | √/- | √ * | _ | | Digital | _ | |
| 4620 Kit 300 FT | 2135.20 | (0.0 to 1999) $\boldsymbol{\Omega}$ | Battery | ✓ | • | √/- | ✓ | _ | | Digital | _ | |
| 4620 Kit 500 FT | 2135.21 | (0.0 to 1999) Ω | Battery | ✓ | , | √/- | ✓ | _ | | Digital | _ | |
| 4630 | 2130.44 | (0.0 to 1999) Ω | Rechargeable Battery | ✓ | | √/- | ✓ | _ | | Digital | - | |
| 4630 Kit 150 FT | 2135.22 | (0.0 to 1999) Ω | Rechargeable Battery | ✓ | , | √/- | √ * | _ | | Digital | _ | |
| 4630 Kit 300 FT | 2135.23 | (0.0 to 1999) Ω | Rechargeable Battery | ✓ | , | √ /- | | _ | | Digital | - | |
| 4630 Kit 500 FT | 2135.24 | (0.0 to 1999) Ω | Rechargeable Battery | ✓ | , | √/- | - | | Digital | _ | | |

^{*} Performing soil resistivity tests with this kit requires two additional auxiliary electrodes not supplied in the 150 ft kit and one additional test lead.

CLAMP-ON

| AEMC Model Number | AEMC CATALOG NUMBER | RESISTANCE Range | POWER Source | VOLTAGE Indication | INDUCTANCE Measurement- mh | SELETABLE FREQUENCY | ALARM | MEMORY | BLUET00TH |
|-------------------------|---------------------------|---------------------|-----------------|--|-------------------------------|------------------------|--------------------------------|-------------------|-----------|
| 6416 | 2141.01 | (0.01 to 1500) Ω | Battery | Voltage Displayed (noise icon, buzzer) | ✓ | | 3 separate alarms (Ω, V and A) | 300 measurements | _ |
| 6417 | 2141.02 | (0.01 to 1500) Ω | Battery | Voltage Displayed (noise icon, buzzer) | ✓ | | 3 separate alarms (Ω, V and A) | 2000 measurements | Yes |
| 6418 | 2141.03 | (0.01 to 1200) Ω | Battery | Noise Icon | _ | ✓ | 2 separate alarms (Ω and A) | 300 measurements | _ |



www.aemc.com

^{**} Clamp-on Ground Resistance Tester can measure system continuity inclusive of all bonding points.

^{***} Must purchase an additional (2) SR182 or (2) MN82 accessory clamps.